



- | | |
|----------------------------------|-------------------------------------|
| 1. "PHONES" jack | 14. "MOD" "CW" toggle switch |
| 2. "SEND" "REC" toggle switch | 15. " Δ FREQ" control |
| 3. "XTALS" control | 16. "XTAL PHASING" control |
| 4. "LIMITER" "OFF" toggle switch | 17. Vernier dial |
| 5. "SELECTIVITY" switch | 18. Main tuning dial |
| 6. "AVC" "MAN" toggle switch | 19. "METER" "RF" "AF" toggle switch |
| 7. "AUDIO GAIN" control | 20. Meter |
| 8. "RF GAIN" control | 21. "FREQ CONTROL" |
| 9. "TUNING LOCK" control | 22. Movable pointer |
| 10. "BAND CHANGE" control | 23. Fixed pointer |
| 11. "MEGACYCLES" window | 24. Vernier pointer |
| 12. "TUNING" control | 25. Plastic chart |
| 13. "BEAT OSC" control | |

Figure 1-2. Radio Receiver, Front Panel Identification